



600 3rd Ave, Laval, QC, H7R 4J4
 Tel: (514)631-2173
 Fax:(450)627-2199
 email: info@aeroneuf.com



Bell 206 Capability List

Part Number	Manufacturer	Description	Aircraft
102-0054-03	R.C.Allen	Attitude Gyro	B-206
103-0022-01	R.C.Allen	Directional Gyro	B-206
10447N01T00	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
124.1013	Rogerson/Kratos	Engine Oil Temperature/Pressure Indicator	B-206
124.1013-1	Rogerson/Kratos	Engine Oil Temperature/Pressure Indicator	B-206
124.1013-2	Rogerson/Kratos	Engine Oil Temperature/Pressure Indicator	B-206
124.1014	Rogerson/Kratos	Dual Fuel Pressure/Loadmeter Indicator	B-206
124.1014-1	Rogerson/Kratos	Dual Fuel Pressure/Loadmeter Indicator	B-206
124.1014-2	Rogerson/Kratos	Dual Fuel Pressure/Loadmeter Indicator	B-206
124.1014-3	Rogerson/Kratos	Dual Fuel Pressure/Loadmeter Indicator	B-206
124.1014-4	Rogerson/Kratos	Dual Fuel Pressure/Loadmeter Indicator	B-206
152HL2W	Lewis Engineering	Turbine Outlet Temperature Indicator	B-206
152HL2W3	Lewis Engineering	Turbine Outlet Temperature Indicator	B-206
200-914-002	Gull Airborne	Fuel Quantity Indicator	B-206
200DC Bell	J.E.T./A.I.M.	Directional Gyro	B-206
205-1BL	J.E.T./A.I.M.	Directional Gyro	B-206
206-062-627-001	Globe Industries	Tach Generator	B-206
206-062-627-003	Globe Industries	Tach Generator	B-206
206-062-627-1	Globe Industries	Tach Generator	B-206
206-062-627-3	Globe Industries	Tach Generator	B-206
206-063-633	Meggitt/Ragen	Fuel Quantity Indicator	B-206
206-063-633-101	Gull Airborne	Fuel Quantity Indicator	B-206
206-063-656-3	Insco	Fuel Quantity Indicator	B-206
206-070-242-001	Garwin/Insco	Turbine Outlet Temperature Indicator	B-206
206-070-242-1	Garwin/Insco	Turbine Outlet Temperature Indicator	B-206
206-070-243-001	Insco	Tachometer Indicator	B-206
206-070-243-003	Insco	Tachometer Indicator	B-206
206-070-243-1	Insco	Tachometer Indicator	B-206
206-070-243-3	Insco	Tachometer Indicator	B-206
206-070-263-001	United	Altimeter, 20K	B-206
206-070-263-003	United	Altimeter, 20K	B-206
206-070-263-005	United	Altimeter, 20K, Lighted	B-206
206-070-263-007	United	Altimeter, 20K, Milli-Bar, Lighted	B-206
206-070-263-009	United	Altimeter, 20K, Milli-Bar, Lighted	B-206
206-070-263-1	United	Altimeter, 20K	B-206
206-070-263-3	United	Altimeter, 20K	B-206
206-070-263-5	United	Altimeter, 20K, Lighted	B-206
206-070-263-7	United	Altimeter, 20K, Milli-Bar, Lighted	B-206
206-070-263-9	United	Altimeter, 20K, Milli-Bar, Lighted	B-206
206-070-264-001	United	Airspeed Indicator	B-206
206-070-264-005	United	Airspeed Indicator	B-206
206-070-264-1	United	Airspeed Indicator	B-206
206-070-264-5	United	Airspeed Indicator	B-206
206-070-265-001	Insco	Dual Tachometer Indicator	B-206
206-070-265-003	Insco	Dual Tachometer Indicator	B-206
206-070-265-005	Insco	Dual Tachometer Indicator	B-206
206-070-265-007	Insco	Dual Tachometer Indicator	B-206

206-070-265-00	Insco	Dual Tachometer Indicator	B-206
206-070-265-01	Insco	Dual Tachometer Indicator	B-206
206-070-265-1	Insco	Dual Tachometer Indicator	B-206
206-070-265-10	Insco	Dual Tachometer Indicator	B-206
206-070-265-11	Insco	Dual Tachometer Indicator	B-206
206-070-265-3	Insco	Dual Tachometer Indicator	B-206
206-070-265-5	Insco	Dual Tachometer Indicator	B-206
206-070-265-7	Insco	Dual Tachometer Indicator	B-206
206-070-265-9	Insco	Dual Tachometer Indicator	B-206
206-070-266-00	Insco	Tachometer Indicator	B-206
206-070-266-00	Insco	Tachometer Indicator	B-206
206-070-266-00	Insco	Tachometer Indicator	B-206
206-070-266-00	Insco	Tachometer Indicator	B-206
206-070-266-00	Insco	Tachometer Indicator	B-206
206-070-266-01	Insco	Tachometer Indicator	B-206
206-070-266-01	Insco	Tachometer Indicator	B-206
206-070-266-1	Insco	Tachometer Indicator	B-206
206-070-266-11	Insco	Tachometer Indicator	B-206
206-070-266-13	Insco	Tachometer Indicator	B-206
206-070-266-3	Insco	Tachometer Indicator	B-206
206-070-266-5	Insco	Tachometer Indicator	B-206
206-070-266-7	Insco	Tachometer Indicator	B-206
206-070-266-9	Insco	Tachometer Indicator	B-206
206-070-267-00	Lewis Engineering	Turbine Outlet Temperature Indicator	B-206
206-070-267-01	Insco	Turbine Outlet Temperature Indicator	B-206
206-070-267-11	Lewis Engineering	Turbine Outlet Temperature Indicator	B-206
206-070-267-7	Lewis Engineering	Turbine Outlet Temperature Indicator	B-206
206-070-268-00	Insco	Torquemeter Indicator	B-206
206-070-268-00	Insco	Torquemeter Indicator	B-206
206-070-268-00	Insco	Torquemeter Indicator	B-206
206-070-268-01	Insco	Torquemeter Indicator	B-206
206-070-268-01	Insco	Torquemeter Indicator	B-206
206-070-268-1	Insco	Torquemeter Indicator	B-206
206-070-268-11	Insco	Torquemeter Indicator	B-206
206-070-268-13	Insco	Torquemeter Indicator	B-206
206-070-268-5	Insco	Torquemeter Indicator	B-206
206-070-268-9	Insco	Torquemeter Indicator	B-206
206-070-274-00	Mid-Continent/General Design	Turn & Slip Indicator	B-206
206-070-274-10	United	Turn & Slip Indicator	B-206
206-070-274-5	R.C.Allen	Turn & Slip Indicator	B-206
206-070-275-00	Insco	Aircraft Clock	B-206
206-070-275-00	Aerosonic	Aircraft Clock	B-206
206-070-275-3	Insco	Aircraft Clock	B-206
206-070-275-5	Aerosonic	Aircraft Clock	B-206
206-070-278-00	Aerosonic	V.S.I.	B-206
206-070-278-00	Aerosonic	V.S.I.	B-206
206-070-278-1	Aerosonic	V.S.I.	B-206
206-070-278-5	Aerosonic	V.S.I.	B-206
206-070-989-00	Insco	Torquemeter Indicator	B-206
206-070-989-1	Insco	Torquemeter Indicator	B-206
206-075-185-00	Insco	Torquemeter Indicator	B-206
206-075-185-00	Insco	Torquemeter Indicator	B-206
206-075-185-1	Insco	Torquemeter Indicator	B-206
206-075-185-10	Insco	Torquemeter Indicator	B-206
206-075-185-10	Insco	Torquemeter Indicator	B-206
206-075-185-10	Insco	Torquemeter Indicator	B-206
206-075-185-3	Insco	Torquemeter Indicator	B-206
206-075-186-00	Insco	Dual Loadmeter/Fuel Pressure Indicator	B-206
206-075-186-00	Insco	Dual Loadmeter/Fuel Pressure Indicator	B-206

206-075-186-005	Insc0	Dual Loadmeter/Fuel Pressure Indicator	B-206
206-075-186-1	Insc0	Dual Loadmeter/Fuel Pressure Indicator	B-206
206-075-186-3	Insc0	Dual Loadmeter/Fuel Pressure Indicator	B-206
206-075-186-5	Insc0	Dual Loadmeter/Fuel Pressure Indicator	B-206
206-075-187-001	Insc0	Oil Temperature/Pressure Indicator	B-206
206-075-187-1	Insc0	Oil Temperature/Pressure Indicator	B-206
206-075-188-001	Insc0	Xmsn Oil Temp/Press Indicator	B-206
206-075-188-003	Insc0	Xmsn Oil Temp/Press Indicator	B-206
206-075-188-005	Insc0	Xmsn Oil Temp/Press Indicator	B-206
206-075-188-1	Insc0	Xmsn Oil Temp/Press Indicator	B-206
206-075-188-3	Insc0	Xmsn Oil Temp/Press Indicator	B-206
206-075-188-5	Insc0	Xmsn Oil Temp/Press Indicator	B-206
206-075-189-001	Insc0	Fuel Quantity Indicator	B-206
206-075-189-003	Insc0	Fuel Quantity Indicator	B-206
206-075-189-1	Insc0	Fuel Quantity Indicator	B-206
206-075-189-3	Insc0	Fuel Quantity Indicator	B-206
206-075-190-001	Insc0	Turbine Outlet Temperature Indicator	B-206
206-075-190-003	Insc0	Turbine Outlet Temperature Indicator	B-206
206-075-190-007	Insc0	Turbine Outlet Temperature Indicator	B-206
206-075-190-1	Insc0	Turbine Outlet Temperature Indicator	B-206
206-075-190-3	Insc0	Turbine Outlet Temperature Indicator	B-206
206-075-190-7	Insc0	Turbine Outlet Temperature Indicator	B-206
206-075-447-007	Leland	Voltage Regulator	B-206
206-075-447-7	Pacific Electro Dynamics	Voltage Regulator	B-206
206-075-606-101	J.E.T./A.I.M.	Directional Gyro	B-206
206-075-606-101	Mid-Continent/General Design	Directional Gyro	B-206
206-075-606-103	R.C.Allen	Directional Gyro	B-206
206-075-606-107	J.E.T./A.I.M.	Directional Gyro	B-206
206-075-607-101	Mid-Continent/General Design	Artificial Horizon	B-206
206-075-607-101	J.E.T./A.I.M.	Attitude Gyro	B-206
206-075-607-103	R.C.Allen	Attitude Gyro	B-206
206-075-676-101	Insc0	Dual Loadmeter/Fuel Pressure Indicator	B-206
206-075-676-103	Rogerson/Kratos	Dual Fuel Pressure/Loadmeter Indicator	B-206
206-075-676-105	Rogerson/Kratos	Dual Fuel Pressure/Loadmeter Indicator	B-206
206-075-676-107	Rogerson/Kratos	Dual Fuel Pressure/Loadmeter Indicator	B-206
206-075-676-109	Rogerson/Kratos	Dual Fuel Pressure/Loadmeter Indicator	B-206
206-075-676-111	Rogerson/Kratos	Dual Fuel Pressure/Loadmeter Indicator	B-206
206-075-677-101	Rogerson/Kratos	Engine Oil Temperature/Pressure Indicator	B-206
206-075-677-103	Rogerson/Kratos	Engine Oil Temperature/Pressure Indicator	B-206
206-075-677-105	Rogerson/Kratos	Engine Oil Temperature/Pressure Indicator	B-206
206-075-680-101	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
206-075-680-103	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
206-075-680-105	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
206-075-680-107	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
206-075-681-013	AMETEK/G.E.	Dual Tachometer Indicator	B-206
206-075-681-105	AMETEK/G.E.	Dual Tachometer Indicator	B-206
206-075-681-115	V.D.O.	Dual Tachometer Indicator	B-206
206-075-681-117	V.D.O.	Dual Tachometer Indicator	B-206
206-075-681-13	AMETEK/G.E.	Dual Tachometer Indicator	B-206
206-075-682-001	AMETEK/G.E.	Gas Producer Tachometer Indicator	B-206
206-075-682-1	AMETEK/G.E.	Gas Producer Tachometer Indicator	B-206
206-075-682-101	R.C.Allen	Gas Producer Tachometer Indicator	B-206
206-075-682-105	V.D.O.	Gas Producer Tachometer Indicator	B-206
206-075-682-107	AMETEK/G.E.	Gas Producer Tachometer Indicator	B-206
206-075-682-109	V.D.O.	Gas Producer Tachometer Indicator	B-206
206-075-714-101	Honeywell	Gyro Horizon	B-206
206-075-725-001	United	Airspeed Indicator	B-206
206-075-725-1	United	Airspeed Indicator	B-206
206-075-725-101	United	Airspeed Indicator	B-206

206-075-739-103	AMETEK/U.S.Gauge	Torque Indicator	B-206
206-075-739-105	AMETEK/U.S.Gauge	Torque Indicator	B-206
206-075-740-107	Insco	Fuel Quantity Indicator	B-206
206-076-373-001	Globe Industries	Tach Generator	B-206
206-076-373-1	Globe Industries	Tach Generator	B-206
206-375-005-101	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
206-375-006-101	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
206-375-007-101	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
206-375-007-103	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
206-375-009-101	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
22-304-4	Garwin	Turbine Outlet Temperature Indicator	B-206
22A649	Globe Industries	Tach Generator	B-206
22A656	Globe Industries	Tach Generator	B-206
2800-6845N1L	Mid-Continent/General Design	Turn & Slip Indicator	B-206
32005-000	Globe Industries	Tach Generator	B-206
32005-008	Globe Industries	Tach Generator	B-206
35060-1117	Aerosonic	V.S.I.	B-206
35060-1145	Aerosonic	V.S.I.	B-206
36300-1154	Aerosonic	Aircraft Clock	B-206
4000-1002	Insco	Aircraft Clock	B-206
4030567-291	Honeywell	Gyro Horizon	B-206
4300-8220L	Mid-Continent/General Design	Artificial Horizon	B-206
4305-7150L	Mid-Continent/General Design	Directional Gyro	B-206
4308-1005	Insco	Torquemeter Indicator	B-206
4308-1007	Insco	Torquemeter Indicator	B-206
4308-1009	Insco	Torquemeter Indicator	B-206
4308-3001	Insco	Torquemeter Indicator	B-206
4308-3008	Insco	Torquemeter Indicator	B-206
4308-3013	Insco	Torquemeter Indicator	B-206
4308-3018	Insco	Torquemeter Indicator	B-206
4308-3021	Insco	Torquemeter Indicator	B-206
4308-3022	Insco	Torquemeter Indicator	B-206
4308-3051	Insco	Torquemeter Indicator	B-206
4308-3055	Insco	Torquemeter Indicator	B-206
475-1	Pacific Electro Dynamics	Voltage Regulator	B-206
5006-1004	Insco	Turbine Outlet Temperature Indicator	B-206
5006-3011	Insco	Turbine Outlet Temperature Indicator	B-206
5021-3001	Insco	Turbine Outlet Temperature Indicator	B-206
5021-3002	Insco	Turbine Outlet Temperature Indicator	B-206
5021-3030	Insco	Turbine Outlet Temperature Indicator	B-206
504-0017-930	J.E.T./A.I.M.	Attitude Gyro	B-206
510-1K	J.E.T./A.I.M.	Attitude Gyro	B-206
5707-3002	Insco	Fuel Quantity Indicator	B-206
5707-3007	Insco	Fuel Quantity Indicator	B-206
5707-3012	Insco	Fuel Quantity Indicator	B-206
5707-3027	Insco	Fuel Quantity Indicator	B-206
5932 A.10	United	Altimeter, 20K	B-206
5932 A.11	United	Altimeter, 20K, Lighted	B-206
5932 A.60	United	Altimeter, 20K, Milli-Bar, Lighted	B-206
5932 A.9	United	Altimeter, 20K	B-206
5934-1 A.89	United	Altimeter, 20K	B-206
5934-1 A.90	United	Altimeter, 20K	B-206
5934A-3 A.91	United	Altimeter, 20K, Lighted	B-206
5934M-1 A.116	United	Altimeter, 20K, Milli-Bar, Lighted	B-206
5934M-1 A.116	United	Altimeter, 20K, Milli-Bar, Lighted	B-206
5934M-1 A.92	United	Altimeter, 20K, Milli-Bar, Lighted	B-206
6501-1001	Insco	Tachometer Indicator	B-206
6501-1005	Insco	Tachometer Indicator	B-206
6501-1011	Insco	Tachometer Indicator	B-206

6501-2004	Insco	Tachometer Indicator	B-206
6501-3003	Insco	Tachometer Indicator	B-206
6501-3007	Insco	Tachometer Indicator	B-206
6501-3009	Insco	Tachometer Indicator	B-206
6501-3010	Insco	Tachometer Indicator	B-206
6501-3018	Insco	Tachometer Indicator	B-206
6502-1001	Insco	Dual Tachometer Indicator	B-206
6502-1014	Insco	Dual Tachometer Indicator	B-206
6502-2004	Insco	Dual Tachometer Indicator	B-206
6502-3003	Insco	Dual Tachometer Indicator	B-206
6502-3010	Insco	Dual Tachometer Indicator	B-206
6502-3031	Insco	Dual Tachometer Indicator	B-206
6502-3046	Insco	Dual Tachometer Indicator	B-206
7000788-135	Honeywell	Gyro Horizon	B-206
7000788-175	Honeywell	Gyro Horizon	B-206
7000788-191	Honeywell	Gyro Horizon	B-206
7000788-195	Honeywell	Gyro Horizon	B-206
8000 B.12	United	Airspeed Indicator	B-206
8000 B.336	United	Airspeed Indicator	B-206
8000 B.4	United	Airspeed Indicator	B-206
8000 B.629	United	Airspeed Indicator	B-206
83-104-1	Meggitt/Ragen	Fuel Quantity Indicator	B-206
8DJ150WAE1	AMETEK/G.E.	Dual Tachometer Indicator	B-206
8DJ150WAH1	AMETEK/G.E.	Dual Tachometer Indicator	B-206
8DJ81WBS4	AMETEK/G.E.	Gas Producer Tachometer Indicator	B-206
8DJ81WDG4	AMETEK/G.E.	Gas Producer Tachometer Indicator	B-206
9009-3003	Insco	Oil Temperature/Pressure Indicator	B-206
9009-3004	Insco	Xmsn Oil Temp/Press Indicator	B-206
9009-3013	Insco	Xmsn Oil Temp/Press Indicator	B-206
9016-3001	Insco	Dual Loadmeter/Fuel Pressure Indicator	B-206
9016-3002	Insco	Dual Loadmeter/Fuel Pressure Indicator	B-206
9016-3003	Insco	Dual Loadmeter/Fuel Pressure Indicator	B-206
9016-3021	Insco	Dual Loadmeter/Fuel Pressure Indicator	B-206
9550 N.589	United	Turn & Slip Indicator	B-206
AW1842BA05	AMETEK/U.S.Gauge	Torque Indicator	B-206
AW1842BA06	AMETEK/U.S.Gauge	Torque Indicator	B-206
DL401-14	V.D.O.	Dual Tachometer Indicator	B-206
DL401-15	V.D.O.	Dual Tachometer Indicator	B-206
DL412-57	V.D.O.	Gas Producer Tachometer Indicator	B-206
DL412-61	V.D.O.	Gas Producer Tachometer Indicator	B-206
DL412-61	V.D.O.	Gas Producer Tachometer Indicator	B-206
GEU-7/A	Globe Industries	Tach Generator	B-206
GH-206	Honeywell	Gyro Horizon	B-206
M5930-02	R.C.Allen	Turn & Slip Indicator	B-206
RCA15BK-1	R.C.Allen	Directional Gyro	B-206
RCA26BK-12	R.C.Allen	Attitude Gyro	B-206
RCA41-04	R.C.Allen	Gas Producer Tachometer Indicator	B-206
SEL-O19BC	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
SEL-O19BD	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
SEL-O19BU	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
SEL-O19BW	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
SEL-O19DR	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
SEL-O19DS	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
SEL-O19DT	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206
SEL-O19ED	AMETEK/U.S.Gauge	Turbine Outlet Temperature Indicator	B-206